


# STEERING ASSEMBLY



Item No.	Order No.	Description	Item No.	Order No.	Description
1	645748	Steering Lever – Lower Rt.	17	604608	Pivot w/Stop & Bearings Rt. (includes items 19, 20, 30 & 31)
2	645749	Steering Lever – Lower Lt.	18	604609	Pivot w/Stop & Bearings Lt. (includes items 19, 20, 30 & 31)
3	645744	Steering Lever – Upper Rt.	19	422559	Sleeve Bearing w/Flange
4	645745	Steering Lever – Upper Lt.	20	243197	Stop Bolt .312-18 x .75
5	643926	Steering Lever Mount	21	257063	Nylon Washer
6	253195	Whiz Bolt .312-18 x 1.5	22	283324	Compression Spring
7	253035	Whiz Nut .312-18	23	253470	Nut .5-13 Nylon Insert
8	422063	Plug – Nylon .75	24	644601	Steering Pivot
9	422508	Step Bushing	25	253179	Whiz Bolt .25-20 x .75 Phil Truss
10	243035	Bolt .25-20 x 1.5	26	253025	Whiz Nut .25-20
11	253850	Nut .25-20 – Lock	27	285032	Damper with Ball Socket
12	247130	Carriage Bolt .312 x .75	28	265680	Ball Stud
13	257019	Washer .25 – Hard	29	729700	Support – Steering Rod
14	252858	Thumb Screw .312-18 3 Prong	30	422557	Sleeve Bearing
15	422179	Grip – Foam	31	422556	Sleeve Bearing w/Flange
16	422095	Vinyl Cap			